



DRILL A 1/4" HOLE
INTO THE SIDE OF THIS
180 TUBE.
VIEW A-A
SOLDER A TUBE BETWEEN
THE TUBE WITH 1/4" HOLE
AND THE TUBE WHICH WAS
CUT OFF WHEN THE COIL
WAS CUT DOWN TO 14.00"

VIEW A-A

